# LED Wallpack (Semi-cutoff)



### **Features**

- ◆ DLC cULus listed
- ◆ AC120-277V/ AC120-347V/AC277-480V
- ◆ 130LM/W
- ◆ Glass/ PC cover optioanl
- ◆ Photocell sensor / Emergeny backup optional
- **♦** IP65
- ◆ Gary/ luxry gold apprerance
- ◆ Simply installation fixtures
- ♦ 5 years warranty
- ◆ Operating temperature: -20°C~45°C

#### Application:

- Wall lighting
- School
- Stores
- Factory
- Warehouse
- Supermarket









### **Parameters**


Model#	Size	Power	Efficacy	Lumen	Input voltage	CRI	Beam angle	ССТ
OLL-WP40-XXK-MZ	- 14.3''*9.4''*7.6''	40W	- 130LM/W	5200LM	AC120-277V	>70	120°	
OLL-WP60-XXK-MZ		60W		7800LM				4000K 5000K 5700K
OLL-WP90-XXK-MZ		90W		11700LM				
OLL-WP120-XXK-MZ		120W		15600LM				
OLL-WP40-XXK-XX-MZ	- 14.3''*9.4''*7.6''	40W	- 130LM/W	5200LM	AC120-347V AC277-480V	>70	120°	4000K
OLL-WP60-XXK-XX-MZ		60W		7800LM				
OLL-WP90-XXK-XX-MZ		90W		11700LM				5000K 5700K
OLL-WP120-XXK-XX-MZ		120W		15600LM				

# **Ordering Guide**


For example: XSY-WP40-XXK-XX-YZ


Brand	Product name	Power	ССТ	Input voltage	Туре	Daylight sensor
OLL	WP	40	XXK	XX	Υ	Z
OLL	WP	40W 60W 90W 120W	40K 4000K 50K 5000K 57K 5700K	Blank AC120-277V HL AC120-347V HV AC277-480V	M Semi-cutoff F Full cutoff	D with sensor N without sensor


## **Dimension**




## **Photometric**











### Installation

#### ALWAYS TURN OFF THE POWER SUPPLY FROM MAIN CIRCUIT BREAKER FIRST!


### **Option 1**








2. Separate the lamp as per the picture below.




3. Fit and adjust the bottom cover at the right position according to the gradienter on the fixture.




4. Drill holes on the wall according to the three screw holes of the bottom housing.




5. Use a hammer to drive the nylon expansion tube into the drilled hole on the wall.




6. Remove one of the G1/2-14 threaded plug at one side of the fixture.




7. The wire inside the junction box runs with listed water proof conduit fitting and conduit and into the lamp.




8. Fix the bottom housing on the wall with a self-tapping screw. Caulk to mounting surface, at all sides.



 Then connect the incoming wire to the lamp's input wire and insulate the bare wires well.



10. Replace the top cover that was removed before installation. Mount the top cover with the base. And connect driver and PCB with the male and female connector




12. Power-on and testing to check if the luminaire works normally, screw up at last if no problems. (Note: Keep the waterproof silicone ring at the original position.)



13. Finish installation.


### Option 2




 Drill holes with percussion drill in line with the hole position from wall




2. Use a hammer to drive the nylon expansion tube into the drilled hole on the wall.




3. Fix the bottom housing on the wall with a self-tapping screw.




4. Align the screws at the screw holes to fix the bracket on the lamp.




5. Separate the lamp housing according to OPTION 1-2, Remove one of the G1/2-14 threaded plug at one side of the fixture.




6. Install the lamp base on the wall mounting bracket




7. Run the wire from the external junction box withListed water proof conduit fitting and conduit into the lamp from the side. Enclose the outlet box with Listed outlet box cover.



8. Then connect the incoming wire to the lamp's input wire and insulate the bare wires well.



 Replace the top cover that was removed before installation.
Mount the top cover with the base. And connect driver and PCB with the male and female connector



 Power-on and testing to check if the luminaire works normally, screw up at last if no problems. (Note: Keep the waterproof silicone ring at the original position.)



11. Finish installation.

### Package Info.

Power	Carton Dimension	Qty / Carton	N.W	G.W	20GP	40HQ
40W/60W	15.87''*11.30''*9.61''	1PCS	9.61lbs	12.12lbs	857pcs	22F7ncc
90W/120W						2357pcs

## **Safety Precaution**

To reduce the risk of death, personal injury or property damage from fire, electric shock, falling parts, cuts/abrasions, and other hazards read all warnings and instructions included with and on the fixture box and all fixture labels.

Before installing, servicing, or performing routine maintenance upon this equipment, follow these general precautions.

Commercial installation, service and maintenance of luminaires should be performed by a qualified licensed electrician.

For The installation: If you are unsure about the installation or maintenance of the luminaires, consult a qualified licensed electrician and check your local electrical code.

To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.

Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation.

#### WARNING: RISK OF FIRE OR ELECTRICAL SHOCK

Turn off electrical power at fuse or circuit breaker box before wiring fixture to the power supply.

Turn off the power when you perform any maintenance.

Verify that supply voltage is correct by comparing it with the luminaire label information.

Make all electrical and grounded connections in accordance with the National Electrical Code and any applicable local code requirements.

All wiring connections should be capped with UL approved wire connectors.

#### **CAUTION: RISK OF INJURY**

Avoid direct eye exposure to the light source while it is on.

Account for small parts and destroy packing material, as these may be hazardous to children.